

FITTING INSTRUCTIONS  
 EINBAUANLEITUNG  
 INSTRUCCIONES DE MONTAJE  
 NOTICE DE MONTAGE  
 ISTRUZIONI DI MONTAGGIO  
 INSTRUKCJA MONTAŻU  
 INSTRUÇÕES DE MONTAGEM  
 ИНСТРУКЦИЯ ПО УСТАНОВКЕ

**micronAir®**

Fiat  
 500 L  
 500 X

09.12 ->  
 02.15 ->

80004572  
 CP1462  
 MP440

Jeep  
 Renegade  
 Compass

09.14 ->  
 09.16 ->

80004719  
 CC1462  
 MC940

49408511  
 CB1462  
 BL940

